

## FIREPIT AND FIREBOWL

1. ALWAYS KEEP A 6" MINIMUM CLEARANCE BETWEEN BURNER AND PRECAST MATERIAL.
2. ONLY USE LAVA ROCK OR FIRE GLASS.
3. ALWAYS USE A REGULATOR WHICH IS NOT INCLUDED.
4. NEVER BURN WOOD.
5. DO NOT OPERATE IN EXCESSIVELY WINDY CONDITIONS.
6. DO NOT OVERHEAT FIREPIT OR BOWL BY BURNING FLAME MORE THAN 8" HIGH.
7. WE SUGGEST THAT ALL OUR PRODUCTS SHOULD BE INSTALLED BY LICENSED PROFESSIONALS.
8. CAREFULLY FOLLOW ALL LOCAL BUILDING CODES TO PREVENT PERSONAL INJURY AND PROPERTY LOSS.