


- **1.1** Install PSD, INC. Pre-cast plumb, true, and level in accordance with installation instructions and the PSD Technical Data Sheet. All pre-cast should be set by experienced and qualified pre-cast masonry installers.
- **1.2** All substrate receiving PSD, INC. Pre-cast shall be cleaned of any oil, paint, dust, debris, etc. Surface shall be smooth, level, and competent of a firm and permanent adhesion to the setting material. <sup>(fig. 2)</sup>
- **1.3** Apply waterproofing (super blockade or equalalent) 3 coats to bond beam as shown. follow manufactures instructions. (fig. 1)
- **1.4** Apply fortified thinset to waterproofed membrain and coping with notched trowl. Appying fortified thinset in same direction.
- 1.5 Apply mortar (spec mix) and set coping.
- 1.6 Grout coping with approved PSD grout. (see grout detail)
- **1.7** Seal all coping with aqua-mix penetrating sealer. Only apply sealer after coping and grout is free of all moisture,this will help avoid damage by other trades. If a foreign matter does contact the pre cast must be removed immediatly.
- **1.8** It is critical that all PSD, INC. Pre-cast shall be protected from splashing mortar or damage by other trades. If a foreign matter does contact the pre-cast it must be removed immediately.
- **1.9** PSD, INC. Pre-cast shall be cleaned where necessary by scrubbing with a bristle fiber brush, using soap powder and water. Then rinse thoroughly and generously with water. No acid or prepared cleaners shall be used without the approval of PSD, INC.





## IMPORTANT NOTICE NOTE: WHEN USING SAND SET DECKING

## RECOMMENDED WATERPROOFING MERLEX "SUPERBLOCKADE" OR EQUIVALENT

## APPLY WATERPROOFING AT EDGE OF COPING TO PREVENT MOISTURE FROM ENTERING





SEALING W/ AQUAMIX PENITRATING SEALER IS HIGHLY RECOMMENDED AFTER GROUT IS APPLIED

> NOTE: 1.) PRECAST TO BE CONNECTED WITH THIN SET W/ ACRYLIC ADMIX AND SPEC MIX 2.) GROUT TO MATCH IN COLOR 3.) JOINT "TBD" O.C.